



Gammacolor s.r.l.
Via Zeuner, 5 20822 Seveso (MB) Italy
tel. +39 0362550550 fax +39 0362551915
email info@gammacolorsrl.com



Associazione Tessile e Salute
Azienda associata

p.IVA 00736390964 C.F. 02639210158 c.c.i.a. Milano n. 927455 Codice ISS azienda 00736390964

MICROEMULSIONE MS

AMINOFUNCTIONAL MICROEMULSION

MICROEMULSIONE MS is a softening microemulsion of amino-funcional silicone. It has been studied for giving to the fabrics a slightly soft finishing, dry, pleasant and pleasantly slippery. **Treatment with MICROEMULSIONE MS remain also during next washings, it lasts much more than traditional cationic softeners**

CHEMICAL AND PHYSICAL FEATURES:

Appearance: liquid
Odor: Typical
Color: transparent
Solubility: completely soluble in water
pH at 20°C: 6.5 ± 0.5
Density (20°C) g / cm³: 0.995 ± 0.010
Viscosity dynamic at 25°C Mpas: 15 to 60
Solid content:%: 35.0 ± 2.0

CHEMICAL AND PHYSICAL CHARACTERISTICS:

Appearance: liquid
Odor: Typical
Color: transparent
Solubility: completely soluble in water
pH at 20°C: 6.5 ± 0.5
Density (20°C) g / cm³: 0.995 ± 0.010
Viscosity dynamic at 25°C Mpas: 15 to 60
Solid content:%: 35.0 ± 2.0

USES AND APPLICATIONS:

MICROEMULSIONE MS was developed specifically as a softener for fibers and tissues. It is used in combination or as an alternative to conventional cationic softening. Characterized by a permanent softening effect that lasts for several washes. The effect you get the fabric is soft, slightly swollen, dry, slippery and pleasant. Despite its amino-cationic nature the product does not transfer any yellowing to the fabric. It is effective on many types of fibers including cotton 100%, cotton -polyester and other synthetic blends.

MICROEMULSION MS can be applied by immersion or extraction process.

For impregnation (soaking) use 20-40 gr/l

Thanks to its high stability to the cutting forces, **MICROEMULSION MS** can be used in all



Gammacolor s.r.l.
Via Zeuner, 5 20822 Seveso (MB) Italy
tel. +39 0362550550 fax +39 0362551915
email info@gammacolorsrl.com



Associazione Tessile e Salute
Azienda associata

p.IVA 00736390964 C.F. 02639210158 c.c.i.a. Milano n. 927455 Codice ISS azienda 00736390964

finishing textile plants. We recommend that dilution of the product should taken place only at the time of its use.

STABILITY AND STORAGE:

MICROEMULSION MS should be used within six months.

Store between +5 and + 30°C in well sealed and possibly filled drum. Do not leave the product for a long time in almost empty drums. In this case, you should transfer the contents remaining in smaller containers.

Keywords: microemulsion, softener, siliconic, silicone, emulsion, soft hand, full hand, slippery hand

The data reported are the result of careful studies and / or experience gained, however must be considered indicative and still no guarantee of employment.

For information: e-mail info@gammacolorsrl.com